


Enter message here using hex values separated by spaces. The Message is validated while typing

Calculated checksum



Information about your entry or response from server.

Uncheck when you want to send invalid messages. Remember that the server may reject your message, so it will not hit loconet.

Uncheck when you want to add the checksum byte yourself

Press when you have finished typing. Is disabled when message is invalid.